

# Product Data Sheet

October 7, 1997

Innovations 97

## Series 3000

### Installation Instructions

#### Description

Thank you for purchasing the Original Mirror Relocation System.

This product has been engineered to give you years of trouble free enjoyment. From the hard-anodized finish on our black brackets to the stainless steel hardware, it will last through years of the elements.

#### Parts List for Series 3000, Full Set

1. (1) Drivers side bracket, marked with "L" on the bottom
2. (1) Passenger side bracket, marked with "R" on the bottom
3. (2) Stainless Steel 3/8-16 x 2 1/4" bolt
4. (2) Stainless Steel Flat washers
5. (2) Stainless Steel Lock washers

1. Remove the doors from the Jeep (Consult your owners' manual for directions)
2. Once the doors have been removed, remove the stock mirror from the bracket that is on the door, using an 11/16" socket. Be careful when you remove the nut because there is a spring, shelf washer and flat washer under it. **Make note of the order in which they are removed.**
3. You may now install your new brackets on the top door hinge using the hardware supplied and tighten the bolt. (*See Drawing Page 2*)
4. Now install the mirror you removed from the door. Installs in the reverse manner in which removed then tighten the nut. **Do not over tighten this nut, it is spring loaded and does not require a lot of torque.**

